



NO	HHAW PARTS NO		Q' TY/UNIT	PARTS NAME		
	RAC-18WPB	RAC-25WPB				
1	HWRAC-18WEB	A01	1	BASE		
2	HWRAC-18WEB	A02	1	COMPRESSOR		
3	HWRAC-18WEB	A03	3	COMPRESSOR RUBBER		
4	HWRAC-18WEB	A04	3	PUSH NUT		
5	HWRAC-18WEB	A05	1	CONDENSER		
6	HWRAC-18WEB	A06	1	REVERSING VALVE		
7	HWRAC-50WEA	A06	1	2S-VALVE		
8	HWRAC-10GH5	A03	1	3S-VALVE		
9	HWRAC-18WEB	A07	1	O. L. R COVER		
10	HWRAC-18WSA	A11	1	CONNECTING CORD (COMP)		
11	HWRAC-E10H2	A09	1	THERMISTOR (DEFROST)		
12	HWRAC-D10EX	A08	1	THERMISTOR SUPPORT		
13	HWRAC-18WEB	A08	1	ELECTRIC EXPAN. VALVE		
14	HWRAC-E08H	A09	1	COIL (EXPAN. VALVE)		
15	HWRAC-18WEB	A09	1	PARTITION		
16	HWRAC-18WEB	A10	1	REACTOR 1		
17	HWRAC-18WEB	A11	1	FAN MOTOR SUPPORT		
18	HWRAC-18WEB	A12	1	FAN MOTOR		
19	HWRAC-18WEB	A13	1	PROPELLER FAN		
20	HWRAC-25YH4	A24	1	NUT (PROPELLER. FAN)		
21	HWRAC-18WEB	A14	1	SIDE COVER (L)		
22	HWRAC-18WEB	A15	1	FRONT COVER		
23	HWRAC-18WEB	A16	1	DISCHARGE GRILL		
24	HWRAC-18WEB	A17	1	ELECTRIC PARTS PLATE		
25	HWRAC-18WEB	A18	1	ELECTRIC PARTS COVER		
26	HWRAC-18WEB	A19	2	TERMINAL BOARD (5P)		
27	HWRAC-18WEB	A20	1	HEAT SINK (REGURATOR 1)		
28	HWRAC-E08H	A11	1	FUSE (15A)		
29	HWRAC-50NX2	A52	2	FUSE (3. 15A)		
30	HWRAC-18WEB	A21	HWRAC-25WEB	A01	1	P. W. B. (MAIN)
31	HWRAC-18WEB	A22	1	FUSE (15A)		
32	HWRAC-18WEB	A23	1	SUPPORT (P. W. B.)		
33	HWRAC-18WEB	A24	1	COVER (OUT DOOR THERMISTOR)		
34	HWRAC-D10EX	A17	1	THERMISTOR (OUT DOOR TEMP.)		
35	HWRAC-18WEB	A25	1	EV-COV-ZU		
36	HWRAC-18WEB	A26	1	T-COVERZU		
37	HWRAC-25YHA4	A50	1	DRAIN PIPE		
38	HWRAC-18WEB	A27	1	NET-LIKE OBJECT		
39	HWRAC-18WEB	A28	1	TERMINAL COVER		
40	HWRAC-18WEB	A29	1	SOUND PROOF COVER ASS' Y		
41	HWRAC-10EH4	A05	1	SOUND PROOF COVER ASS' Y		
42	HWRAC-18WEB	A30	1	SOUND PROOF COVER ASS' Y		
43	HWRAC-18WEB	A31	1	SOUND PROOF COVER ASS' Y		
44	HWRAC-SX10HAK	A20	1	COIL (REVERSING VALVE)		
45	HWRAC-18WEB	A32	1	SIDE COVER (R)		