



NO	JCH-WH PARTS NO	Q' TY/UNIT	PARTS NAME
1	HWRAC-50FXE A01	1	BASE
2	HWRAC-50WXD A02	1	COMPRESSOR
3	HWRAC-50WEC A08	1	SOUND PROOF
4	HWRAC-50NX2 A04	3	PUSH NUT
5	HWRAC-50WXD A03	1	CONDENSER
6	HWRAC-50WSE A01	1	REVERSING VALVE ASSEMBLY
7	HWRAC-50WEA A05	1	SERVICE VALVE
8	HWRAC-50WEA A06	1	SERVICE VALVE
9	HWRAC-50WED A03	1	ELECTRIC EXPANSION VALVE
10	HWRAC-50WXD A05	1	SOUND PROOF
11	HWRAC-50WXD A06	1	SOUND PROOF
12	HWRAC-50WXD A07	1	SOUND PROOF
13	HWRAC-50WSE A02	1	SOUND PROOF
14	HWRAC-50WXD A09	1	SOUND PROOF
15	HWRAC-50WEA A12	1	CONNECTING CORD (COMPRESSOR)
16	HWRAC-50WXB A28	1	THERMISTOR (DEFROST)
17	HWRAC-50WXD A10	1	THERMISTOR SUPPORT
18	HWRAC-25WXD A09	1	COIL (REVERSING VALVE)
19	HWRAC-50WED A07	1	COIL (EXPANSION VALVE)
20	HWRAC-50WXD A11	1	PARTITION
21	HWRAC-50WED A09	1	REACTOR
22	HWRAC-50WXD A12	1	FAN MOTOR SUPPORT
23	HWRAC-50WED A10	1	FAN MOTOR
24	HWRAC-50WXB A07	1	PROPELLER FAN
25	HWRAC-50NX2 A25	1	NUT (PROPELLER FAN)
26	HWRAC-50WXB A09	1	NET LEFT
27	HWRAC-50WXB A10	1	LEFT PLATE
28	HWRAC-50WXDN A04	1	FRONT COVER
29	HWRAC-50WXB A12	1	DISCHARGE GRILL
30	HWRAC-50WED A17	1	FUSE (25A)
31	HWRAC-50WXB A14	1	THERMI-C
32	HWRAC-50FXE A02	1	SIDE COVER (R)
33	HWRAC-14EH4 A15	1	COVER (OUT DOOR THERMISTOR)
34	HWRAC-50WXB A27	3	PC-SUP
35	HWRAC-50WXB A18	1	TER-PLATE
36	HWRAC-50FXE A03	1	TOP COVER
37	HWRAC-50WXD A15	1	TERMINAL-COVERAS
38	HWRAC-50WXD A16	1	EV-COVER
39	HWRAC-50FXE A04	2	HANDLE
40	HWRAC-50WXB A23	1	DRAIN PIPE
41	HWRAC-50WXB A24	1	ELECTRIC PARTS PLATE
42	HWRAC-50WXD A17	1	ELECTRIC PARTS COVER
43	HWRAC-50WEB A07	2	SUPPORT (P. W. B.)
44	HWRAC-50WEB A08	1	HEAT SINK
45	HWRAC-50FXE A05	1	P. W. B. (MAIN)
46	HWRAC-50WEB A10	1	ASSEMBLY
47	HWRAC-50WEB A11	2	CORD ASSEMBLY
48	HWRAC-50WED A16	1	TERMINAL BOARD (5P)
49	HWRAC-25WXD A08	1	O. L. R COVER
50	HWRAC-25WXD A11	2	FUSE (3. 15A)
51	HWRAC-50WEB A13	1	SUPPORT (P. W. B.)
52	HWRAC-50WXB A32	4	MIRROR MAT
53	HWRAC-50WXB A26	1	FIX-PLATE
54	HWRAC-50WXD A19	1	SOUND PROOF