



NO.	HHAW PARTS NO.	Q' TY/UNIT	PARTS NAME
1	HWRAC-35WEA A01	1	BASE
2	HWRAC-35WEA A02	1	COMPRESSOR
3	RAC-25EVX 002	3	COMPRESSOR RUBBER
4	HWRAC-25YH4 A04	3	PUSH NUT
5	HWRAC-E14H3 901	1	CONDENSER
6	HWRAC-35WEA A03	1	REVERSING VALVE(WITH COIL)
7	RAC-A25BXA 061	1	2S-VALVE
8	RAC-A25BXA 060	1	3S-VALVE
9	HWRAC-E14H3 902	1	ELECTRIC EXPAN. VALVE
10	HWRAC-E08H A07	1	O. L. R COVER
11	HWRAC-25YH4 A11	1	O. H THERMI. SUPPORT
12	RAC-25DVY 003	1	CONNECTING CORD (COMP)
13	HWRAC-D10EX A08	1	THERMISTOR (DEFROST)
14	HWRAS-25YH4 A15	1	SPRING
15	HWRAC-E14H3 904	1	COIL (REVERS. VALVE)
16	HWRAC-E14H3 905	1	COIL (EXPAN. VALVE)
17	HWRAC-SX10HAK A23	1	PARTITION
18	HWRAC-25YH4 A18	1	REACTOR COVER
19	HWRAC-E14H3 906	1	REACTOR 1
20	HWRAC-X13HAK A04	1	REACTOR 2
21	HWRAC-14EH4 A08	1	FAN MOTOR SUPPORT ASS' Y
22	HWRAC-50NX2 A23	1	FAN MOTOR
23	HWRAC-14EH4 A09	1	PROPELLER FAN
24	HWRAC-25YH4 A24	1	NUT (PROPELLER. FAN)
25	HWRAC-25YH4 A25	1	SIDE COVER (L)
26	HWRAC-25YH4 A26	1	HANDLE
27	HWRAC-14EH4 A10	1	FRONT COVER
28	HWRAC-E14H3 909	1	DISCHARGE GRILL
29	HWRAC-14EH4 A11	1	COVER(CAPACITOR)
30	HWRAC-35WEA A04	1	ELECTRIC PARTS PLATE
31	HWRAC-14EH4 A13	1	ELECTRIC PARTS COVER
32	HWRAC-25YH4 A32	2	TERMINAL BOARD (2P)
33	HWRAC-25YHA3 A09	1	HEAT SINK (REGURATOR 1)
34	HWRAC-E08H A11	1	FUSE (15A)
35	HWRAC-25YHA3 A10	1	FUSE (3. 15A)
36	HWRAC-25YHA3 A11	1	VARIATOR
37	HWRAC-35WEA A05	1	P. W. B. (MAIN)
38	HWRAC-25YHA3 A13	1	FUSE (2A)
39	HWRAC-25YHA3 A14	1	SUPPORT (P. W. B.)
40	HWRAC-25YHA3 A15	1	CAPACITOR
41	HWRAC-14EH4 A15	1	COVER (OUT DOOR THERMISTOR)
42	HWRAC-E14H3 914	1	THERMISTOR (OUT DOOR TEMP.)
43	HWRAC-E14H3 915	1	SIDE COVER (R)
44	HWRAC-25YHA3 A17	1	TERMINAL COVER
45	HWRAC-14EH4 A16	1	TOP COVER
46	HWRAC-25YH4 A47	1	SERVICE VALVE COVER
47	HWRAC-25YH4 A48	1	BUSH ASS' Y
48	HWRAC-25YH4 A49	1	BUSH
49	HWRAC-25YH4 A50	1	DRAIN PIPE
50	HWRAC-SX10HAK A12	1	SOUND PROOF COVER ASS' Y
51	HWRAC-SX10HAK A09	1	SOUND PROOF COVER ASS' Y
52	HWRAC-SX10HAK A10	1	SOUND PROOF COVER ASS' Y
53	HWRAC-SX10HAK A11	1	SOUND PROOF COVER ASS' Y