



NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	KPNT1 001	6	PUSH NUT
2	PMRAC-24CP5 905	1	TOP COVER
3	PMRAC-25NH4 S09	1	OVERHEAT THERMISTOR SUPPORT
4	PMRAM-72QH5 918	1	VALVE (4S)
5	PMRAC-63CA1 S02	1	TERMINAL BOARD (2P)
6	PMRAC-70YHA 908	1	SIDE PLATE L
7	PMRAC-70YHA 916	1	NET COVER
8	PMRAC-70YHA S05	1	D-GRILL-AS (INCL. MOUTH RING)
9	PMRAC-70YHA S06	1	NET
10	PMRAC-70YHA S07	1	PROPELLER FAN
11	PMRAC-70YHA S12	1	SUPPORT (FAN MOTOR)
12	PMRAC-70YHA S13	1	THERMISTOR (DEFROST)
13	PMRAC-VX13CET S04	4	TERMINAL BOARD (3P)
14	PMRAC-X13CX 902	4	VALVE (2S)
15	PMRAC-X18CD S04	1	REACTOR
16	PMRAM-33NP2B S06	1	COIL (REVERSING VALVE)
17	PMRAM-33NP2B S07	1	REVERSING VALVE
18	PMRAM-53NP2B S07	4	EXPANSION VALVE
19	PMRAM-53NP2B S08	1	EXPANSION VALVE COIL (W)
20	PMRAM-53NP2B S09	1	EXPANSION VALVE COIL (R)
21	PMRAM-53NP2B S10	1	FAN MOTOR
22	PMRAM-53NP3B S05	1	EXPANSION VALVE COIL (B)
23	PMRAM-65QH4 S10	1	THERMISTOR (OUTSIDE TEMPERATURE)
24	PMRAM-65QH4 S20	1	STRAINER (CO-PIPE-AS 1)
25	PMRAM-68NP3A S07	1	CABINET
26	PMRAM-68NP3B S06	1	COMPRESSOR
27	PMRAM-70NP4B S01	1	P.W.B. (MAIN)
28	PMRAM-70NP4B S02	1	P.W.B. (INVERTER)
29	PMRAM-70NP4B S03	1	EXPANSION VALVE COIL (BC)

NO.	PART NO.	Q'TY / UNIT	PARTS NAME
30	PMRAM-72Q8 S03	1	THERMISTOR (OH)
31	PMRAM-72QH5 909	1	STRAINER (ST-PIPE-AS 1)
32	PMRAM-72QH5 910	1	STRAINER (ST-PIPE-AS 2)
33	PMRAM-72QH5 911	1	STRAINER (ST-PIPE-AS 3)
34	PMRAM-72QH5 912	1	STRAINER (ST-PIPE-AS 4)
35	PMRAM-72QH5 913	1	SV-COVER
36	PMRAM-72QH5 S04	1	CONDENSER
37	PMRAM-72QH5 S14	1	SIDE PLATE R
38	PMRAM-72QH5 S15	1	THERMISTOR-PIPE (W)
39	PMRAM-72QH5 S16	1	THERMISTOR-PIPE (R)
40	PMRAM-72QH5 S20	1	SUPPORT (DEF-THERMISTOR)
41	PMSMARTY235M 902	3	VALVE (3S)
42	RAC-2226HV 805	3	COMPRESSOR RUBBER