





NO	JCH-WH PARTS NO	Q' TY/UNIT	PARTS NAME
1	HWRAK-18RPD A01	1	CABINET ASS' Y
2	HWRAK-18RPD A02	1	STEPPING MOTOR
3	HWRAS-K10HCG 903	1	FAN MOTOR
4	HWRAK-18PSFA 902	1	TANGENTIAL AIR FLOW FAN
5	HWRAK-18PED A03	1	FAN SUPPORT ASS' Y
6	HWRAK-18PED A04	1	FAN MOTOR SUPPORT-R
7	HWRAK-18RPD A03	1	FAN MOTOR SUPPORT-L
8	HWRAK-18RPD A04	1	EVAPORATOR ASS' Y
	HWRAK-50RPD A01	1	EVAPORATOR ASS' Y
9	HWRAK-18RPD A05	1	PIPING ASS' Y
	HWRAK-50RPD A02	1	PIPING ASS' Y
10	HWRAK-18PED A08	1	UPPER COVER
11	HWRAS-25YH4 A15	1	SPRING
12	HWRAS-K10HCG 908	1	TERMINAL BOARD (3P)
13	HWRAK-18RPD A06	1	THERMISTOR ASS' Y
14	HWRAK-18PED A11	1	COVER (ELECTRIC)
15	HWRAK-15QPD A01	1	P. W. B. (MAIN)
	HWRAK-18RPD A07	1	P. W. B. (MAIN)
	HWRAK-25RPD A01	1	P. W. B. (MAIN)
	HWRAK-35RPD A01	1	P. W. B. (MAIN)
	HWRAK-42RPD A01	1	P. W. B. (MAIN)
	HWRAK-50RPD A03	1	P. W. B. (MAIN)
16	HWRAK-15QPD A02	1	ELEC-COVER
	HWRAK-18PED A13	1	ELEC-COVER
17	HWRAK-18RPD A08	1	INDICATION BOX
18	HWRAK-18PED A15	1	LED-COVER
19	HWRAK-18PED A16	1	FC-GUIDE
20	HWRAK-18RPD A09	1	M-COVER
21	HWRAK-18PSFA 919	1	DRAIN CAP
22	HWRAK-18RPD A10	1	DRAINAGE PIPE
23	HWRAK-18PED A18	1	STEPPING MOTOR
24	HWRAS-25YH4 A28	2	DEFLECTOR SUPPORT
25	HWRAK-18PED A19	1	HORIZONTAL AIR DEFLECTOR
26	HWRAK-18PED A20	2	AIR FILTER
27	HWRAK-18RPD A11	1	FRONT PANEL
28	HWRAK-35RPC 906	1	REMOTE CONTROL ASS' Y
29	HWRAK-18RPD A12	1	FRONT COVER
30	HWRAK-18PED A23	1	T-COVER ASS' Y
31	HWRAK-18RPD A13	1	H-LABEL
32	HWRAK-18PED A25	1	S-COVER-L
33	HWRAK-18PED A26	1	S-COVER-R
34	HWRAK-18PED A27	1	MOUNTING PLATE
35	HWRAK-18PPB 902	1	RE-HOLDER
36	HWRAK-18RPD A14	2	VERTICAL AIR DEFLECTOR
37	HWRAK-18RPD A15	8	VERTICAL AIR DEFLECTOR
38	HWRAK-18RPD A16	1	LINK-PLATE
39	HWRAK-18RPD A17	1	10PCORD-AS
40	HWRAK-18RPD A18	1	HUMAN SENSOR ASS' Y
41	HWRAK-18RPD A19	1	HUMAN SENSOR COVER
42	HWRAK-18RPD A20	1	P. W. B. (HUMAN SENSOR)
43	HWRAK-18PPB 905	2	C-CASE
44	HWRAK-18RPD A21	1	VERTICAL AIR DEFLECTOR
45	HWRAC-25WXD A11	1	FUSE (3. 15A)